SafetyFirst®

Instructions For Use



Power cuts are comfortable and precise



Box cutting side buttons and the ultra sharp blade maintain optimum cutting position for cutting tops of boxes



EZ3" Safety Cutter



Blade Change Using the SP-017 singlenotch blade



Rotate blade change wheel counterclockwise until cutter body opens



Remove Spare Blade from blade compartment



Insert Blade underneath blade retainer, aligning blade notch with alignment tab. Close cutter body, rotating wheel clockwise to tighten. Dispose of used blade safely.

General Safety Tips for Cutting

through most packaging materials

The most common cause of accidents related to box cutters take place when an employee uses a standard knife and is distracted or slips while cutting the top of a box and strikes his/her forearm or thigh with an exposed blade. Remember to always:

- Approach work in a balanced body position
- Turn the item to be cut 5 degrees to the left so you are cutting away from the body
- Look at the cut line never look away or become distracted by talking with someone
- Place your other hand on the opposite side of the case away from the cutting line
- When not in use, see that you store your knife or cutter in a safe location. Make sure the blade is safely stored away.
- Utility knives, box cutters or any safety knives or cutters should be discarded or repaired
 if not working properly. The safety features of knives and cutters should not be circumvented or removed. Knives with damaged safety mechanisms should be discarded.
- Utility knives work best when they're sharp. They are easier to operate and safer to use when sharp.
- Use knives and cutters for their intended purpose. Using your knife in a way for which it was not designed or on the wrong materials can damage the blade and cause injury to yourself or others.

For Information Call: (800) 229-2233 Email: info@go-phc.com www.go-phc.com



Working Safe Everyday.™